

## Installation Recommendations

### for AIRFLOOR® / AIRFLEX®



#### **PREPARATION**

- Remove uneven parts of the surface and sharp-edges
- Clean backing thoroughly as it has to be dry, and free of dust and oil for adhesion improvement

#### **INSTALLATION**

- Roughly trim the AIRFLOOR / AIRFLEX to the required size using a carpet-knife
- Fit in the AIRFLOOR / AIRFLEX exactly by cutting it with scissors, a carpet knife or even a air driven milling cutter
- AIRFLOOR / AIRFLEX can be applied and fastened to the surface by using a double-back tape (Scotch 950 (3M) / 708 (Polykene) / P55 Permacell). Fix the adhesive tape along the edges of the surface first, then stick it in parallel stripes on the floor in a distance of 1 – 2 cm.
- Install the AIRFLOOR / AIRFLEX by fixing one edge first, then adjust it exactly and stick it completely to the floor. In order to avoid air bubbles, make sure the edge of the AIRFLOOR / AIRFLEX is free of double back tape. If more than one sheet is installed, ensure that there is a joint of approx. 1/10" – 2/10" left between the AIRFLOOR / AIRFLEX sheets!
- Under the joint install one stripe of double back tape, and than seal it as instructed using FLOORSIL
- Press the sheet to the surface with a roll to improve the adhesion.

#### **Caution**

Wearing of latex rubber gloves and safety glasses is recommended

#### **IMPORTANT NOTE**

Seal AIRFLOOR / AIRFLEX *exclusively* with FLOORSIL !!

Follow the attached instructions regarding the use of FLOORSIL !!

#### **ADDITIONAL INFORMATION ABOUT AIRFLOOR / AIRFLEX**

AIRFLOOR / AIRFLEX may also be installed as a cove, (i.e. the edges can be folded over 1 or 2 inches up the wall and so build a seamless basin).

#### **RESISTANCE TO CONTAMINANTS**

AIRFLOOR / AIRFLEX has a silicon surface which is resistant to all types of beverages, food and other possible contaminants, (e.g. cosmetics, soap, urine, deicingfluid and saltwater).

The silicon surface is not affected by any kind of waste or liquid and AIRFLOOR / AIRFLEX is very easy to clean.

#### **CLEANING INSTRUCTION:**

Only vacuuming or if necessary for cleaning of the silicon surface only use water or a standard cleaning agent for carpeting.

#### **TEMPERATURE DURING INSTALLATION:**

Airfloor and Airflex do not have any constraints on temperature for installation but the Installer should consult the adhesive manufacturer for recommended temperature condition and surface preparation for optimum adhesive performance

Prepared: Bormuth	Date of first Issue: 15.12.00	Released: G. Cluett: 08.07.09	Issue: Issue 7	Date: 25.09.2012	Changed / Date: : Möller / 03.12.2012	Print Date: 26.03.13
----------------------	----------------------------------	----------------------------------	-------------------	---------------------	--	-------------------------